

ДЕТАЛИРОВОЧНАЯ СХЕМА КОТЛА

Модель

R40

R8203402-01 - 06/12/2013

R40


Gas-wall condensing boilers

1	3581364	R40/50 IP WATER HEATER	06-2013	-
1	3581365	R40/50	06-2013	-
2	3581363	R40/65	06-2013	-
2	3581370	R40/65 IP WATER HEATER	-	-
3	3581366	R40/85	06-2013	-
3	3581371	R40/85 IP WATER HEATER	-	-
4	3581367	R40/100	06-2013	-
4	3581372	R40/100 IP WATER HEATER	06-2013	-
5	3581368	R40/120	06-2013	-
5	3581373	R40/120 IP WATER HEATER	-	-
6	3581369	R40/150	06-2013	-
6	3581374	R40/150 IP WATER HEATER	-	-
Col	Reference	Model type	Begin	End


100
200

R40

Gas-wall condensing boilers



	Description	Manf. Pt. N	Type	R40/50 R40/85 R40/85 R40/100 R40/120 R40/150																		31	
				1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18		
0100	ГОРЕЛКА																						
0101	ЭЛЕКТРОД РОЗЖИГА+ПРОКЛАДКА	64201859		●	●	●	●	●	●														
0102	ЭЛЕКТРОД ИОНИЗАЦИИ+ПРОКЛАДКА	64201860		●	●	●	●	●	●														
0103	КОМПЛЕКТ ПРОКЛАДОК ГОРЕЛКИ	64201744		●	●	●																	
	КОМПЛЕКТ ПРОКЛАДОК ГОРЕЛКИ	64201745					●	●	●														
0104	КАБЕЛЬ ЭЛЕКТРОДА РОЗЖИГА	64201857		●	●	●	●	●	●														
0105	КАБЕЛЬ ЭЛЕКТРОДА ИОНИЗАЦИИ	64201858		●	●	●	●	●	●														
0106	КОМПЛЕКТ ПРОКЛАДОК	64201691		●	●	●																	
	КОМПЛЕКТ ПРОКЛАДОК	64201692					●	●															
	КОМПЛЕКТ ПРОКЛАДОК	64201693							●														
0107	ГЛЯДЕЛКА В СБОРЕ	64201730		●	●	●	●	●	●														
0108	КОМПЛЕКТ МАНЖЕТ D:45-22-9.5	64201769		●	●	●																	
	КОМПЛЕКТ МАНЖЕТ D:50-28-9.5	64201770					●	●	●														
0109	КОМПЛЕКТ ПРОКЛАДОК	64201683		●	●	●																	
	КОМПЛЕКТ ПРОКЛАДОК D30-11/4Z	64201684					●	●	●														
0110	ПРОКЛАДКА D:327.5	64201796		●	●	●																	
	ПРОКЛАДКА D:432.5	64201797					●	●	●														
0111	ТЕПЛООБМЕННИК 100	64201853					●																
	ТЕПЛООБМЕННИК 120	64201854						●															
	ТЕПЛООБМЕННИК 145	64201855							●														
	ТЕПЛООБМЕННИК 50-65	64201851		●	●																		
	ТЕПЛООБМЕННИК 85	64201852				●																	
0112	ПРОКЛАДКА	64201798		●	●	●	●	●	●														
0113	ТЕПЛОИЗОЛЯЦИОННАЯ ЛЕНТА TH L	64201955		●	●	●	●	●	●														
0114	ГОРЕЛКА R40/120	64201754							●														
	ГОРЕЛКА R40/50 65	64201751		●	●																		
	ГОРЕЛКА R40/85	64201752				●																	
	ГОРЕЛКА R40/100	64201753					●																
	ГОРЕЛКА R40/150	64201755							●														
0115	ПРОКЛАДКА ЭЛЕКТРОДА РОЗЖИГА	64201920		●	●	●	●	●	●														
0116	ПРОКЛАДКА ЭЛЕКТРОДА ИОНИЗАЦИИ	64201921		●	●	●	●	●	●														
0200	ГАЗОВАЯ ЧАСТЬ																						
0201	ГАЗОВЫЙ КЛАПАН	64201732		●	●																		
	ГАЗОВЫЙ КЛАПАН	64201733				●	●	●	●														
0202	ВЕНТИЛЯТОР В СБОРЕ R40/65	64201734			●																		
	ВЕНТИЛЯТОР В СБОРЕ R40/120	64201736							●														
	ВЕНТИЛЯТОР В СБОРЕ R40/85-100	64201735				●	●																
	ВЕНТИЛЯТОР В СБОРЕ R40/150	64201737								●													
	ВЕНТИЛЯТОР В СБОРЕ R40/50	64201880		●																			
0203	ФЛАНЕЦ С ПРОКЛАДКАМИ R40/100 120	64201772					●	●															
	ФЛАНЕЦ С ПРОКЛАДКАМИ R40/150	64201773							●														
	ФЛАНЕЦ С ПРОКЛАДКАМИ R40/ 50 85	64201771		●	●	●																	
0204	ПРОКЛАДКА D: 24-17-2	64201915		●	●																		
	ПРОКЛАДКА D: 30-22-2	64201916				●	●	●	●	●													
0205	ТЕРМОСТАТ ПЕРЕГРЕВА 100°С	64201897		●	●	●	●	●	●	●													
0206	ПРОКЛАДКА D:82 2 шт.	64201899		●	●	●	●	●	●														
	ПРОКЛАДКА R40/150	64201922							●														
0207	ПРИСОЕДИНЕНИЕ+О-КОЛЬЦО	64201911				●	●	●	●	●													
0208	КАБЕЛЬ ГАЗОВОГО КЛАПАНА	64201990		●	●	●	●	●	●	●													
0212	ЗАВИХРИТЕЛЬ R40/50 65	64201740		●	●																		
	ЗАВИХРИТЕЛЬ R40/150	64201742								●													
	ЗАВИХРИТЕЛЬ R40/120	64201741				●	●	●	●														
0250	ГАЗОВАЯ ТРУБА R40/100	64201748					●																
	ГАЗОВАЯ ТРУБА R40/ 120	64201749						●															
	ГАЗОВАЯ ТРУБА R40/150	64201750							●														
	ГАЗОВАЯ ТРУБА R40/85	64201747				●																	
	ГАЗОВАЯ ТРУБА R40/65	64201746			●																		
	ГАЗОВАЯ ТРУБА R40/50	64201881		●																			




	Description	Manf. Pt N	Type	R40/80 R40/85 R40/85 R40/100 R40/120 R40/150 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18																		31			
0300	ДЫМОУДАЛЕНИЕ																								
0301	ТРУБА ДЫМОХОДА D:110 L:640 мм	64201695		●	●	●																			
	ТРУБА ДЫМОХОДА D:110 L:700 мм	64201696					●	●																	
	ТРУБА ДЫМОХОДА D:125 L:780 мм	64201698											●												
0302	АДАПТЕР ВОЗДУХОВОДА DN100	64201699		●	●	●	●	●																	
	АДАПТЕР ВОЗДУХОВОДА DN130	64201701											●												
0303	АДАПТЕР ДЫМОХОДА D:100 мм	64201700		●	●	●	●	●																	
	АДАПТЕР ДЫМОХОДА D:130 мм	64201702											●												
0304	КОЛЛЕКТОР ДЫМОХОДА	64201687		●	●	●																			
	КОЛЛЕКТОР ДЫМОХОДА	64201688					●	●	●																
0306	ПРОКЛАДКА D:150-110 2 шт.	64201719		●	●	●	●	●																	
	ПРОКЛАДКА D:180-130 2 шт. DN125	64201720											●												
0308	ТРУБА ДЫМОХОДА D:110-125 мм	64201697					●	●																	
0309	ДАТЧИК ТЕМПЕРАТУРЫ NTC	64201645		●	●	●	●	●	●																
0310	ПАТРУБОК СЛИВА КОНДЕНСАТА	64201690		●	●	●	●	●	●																
0311	СИФОН	64201689		●	●	●	●	●	●																
0312	МАНЖЕТА D:100 мм	64201756		●	●	●	●	●																	
	МАНЖЕТА D:130 мм	64201759											●												
0313	МАНЖЕТА D:110 мм	64201757		●	●	●	●	●																	
	МАНЖЕТА D:125 мм	64201758											●												
0314	МАНЖЕТА D:110 мм	64201757					●	●																	
0315	МАНЖЕТА D:110 мм	64201757		●	●	●																			
	МАНЖЕТА D:125 мм	64201758					●	●	●																
0316	МАНЖЕТА D:150 мм	64201760		●	●	●	●	●	●																
0400	КОРПУС																								
0401	ДВЕРЦА ПАНЕЛИ УПРАВЛЕНИЯ СИН.	64201743		●	●	●	●	●	●																
0402	ДВЕРЦА ПАНЕЛИ УПРАВЛЕНИЯ ПРОЗР.	65105749		●	●	●	●	●	●																
0403	ПЕТЛЯ	65105784		●	●	●	●	●	●																
0407	УПЛОТНИТЕЛЬ L:3.5 м	64201721		●	●	●	●	●	●																
0414	КОЖУХ R40/100-150	64201766					●	●	●																
	КОЖУХ R40/50-85	64201764		●	●	●																			
0415	КЛИПСЫ	64201731		●	●	●	●	●	●																
0416	ЗАМОК	12035603		●	●	●	●	●	●																
																						</			

500
600
800

R40

Gas-wall condensing boilers



5000




	Description	Manf. Pt. N	Type	R40/50 R40/65 R40/85 R40/100 R40/120 R40/150 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18																		31	
0500	ГРУППА ПОДАЧИ																						
0501	ВОЗДУХООТВОДЧИК	64201694		●	●	●	●	●	●														
0502	КОЛЛЕКТОР ПОДАЧИ R40/85	64201704				●																	
	КОЛЛЕКТОР ПОДАЧИ R40/120	64201706						●															
	КОЛЛЕКТОР ПОДАЧИ IP	64202248						●															
	КОЛЛЕКТОР ПОДАЧИ IP	64202246	IP	●	●																		
	КОЛЛЕКТОР ПОДАЧИ IP	64202247	IP			●																	
	КОЛЛЕКТОР ПОДАЧИ IP	64202249	IP						●														
	КОЛЛЕКТОР ПОДАЧИ IP	64202250	IP							●													
	КОЛЛЕКТОР ПОДАЧИ R40/65	64201703		●	●																		
	КОЛЛЕКТОР ПОДАЧИ R40/100	64201705						●															
	КОЛЛЕКТОР ПОДАЧИ R40/150	64201707									●												
0503	КОМПЛЕКТ ПРОКЛАДОК	64201683		●	●	●																	
	КОМПЛЕКТ ПРОКЛАДОК	64201684						●	●	●													
0504	РЕЛЕ ДАВЛЕНИЯ	64201865		●	●	●	●	●	●	●													
0551	КОМПЛЕКТ ПАТРУБКОВ ПОДАЧИ R40/50-85	64201762		●	●	●																	
	КОМПЛЕКТ ПАТРУБКОВ ПОДАЧИ IP 100-150	64202252	IP					●	●	●													
	КОМПЛЕКТ ПАТРУБКОВ ПОДАЧИ IP 50-85	64202251	IP	●	●	●																	
	КОМПЛЕКТ ПАТРУБКОВ ПОДАЧИ R40/ 100-150	64201763						●	●	●													
0580	КОМПЛЕКТ МАНЖЕТ D:45-22-9.5	64201769		●	●	●																	
	КОМПЛЕКТ МАНЖЕТ D:50-28-9.5	64201770						●	●	●													
0600	ГРУППА ВОЗВРАТА																						
0601	КОМПЛЕКТ ПАТРУБКОВ ВОЗВРАТА 100-150	64201716						●	●	●													
	КОМПЛЕКТ ПАТРУБКОВ ВОЗВРАТА 50-85	64201715		●	●	●																	
	КОМПЛЕКТ ПАТРУБКОВ ВОЗВРАТА IP 100-150	64202254	IP					●	●	●													
	КОМПЛЕКТ ПАТРУБКОВ ВОЗВРАТА IP 50-85	64202253	IP	●	●	●																	
0602	КОЛЛЕКТОР ВОЗВРАТА 100-150	64201709						●	●	●													
	КОЛЛЕКТОР ВОЗВРАТА IP 100-150	64202256	IP					●	●	●													
	КОЛЛЕКТОР ВОЗВРАТА IP 50-85	64202255	IP	●	●	●																	
	КОЛЛЕКТОР ВОЗВРАТА 50-85	64201708		●	●	●																	
0603	ДАТЧИК ТЕМПЕРАТУРЫ NTC	64201645		●	●	●		●	●	●													
0800	ЭЛЕКТРИЧЕСКАЯ ЧАСТЬ																						
0802	ПРЕДОХРАНИТЕЛЬ 6.3А 250В 2 шт.	64201792		●	●	●	●	●	●	●													
0803	КНОПКА ВКЛ/ВЫКЛ С ПОДСВЕТКОЙ	64200294		●	●	●	●	●	●	●													
0807	ТРАНСФОРМАТОР ZAG2 10Va	64201912		●	●	●	●	●	●	●													
0808	КРОНШТЕЙН ТРАНСФОРМАТОРА R40/ 100-150	64202228						●	●	●													
	КРОНШТЕЙН ТРАНСФОРМАТОРА R40/ 50-85	64202227		●	●	●																	
0814	ПЕРЕДНЯЯ КРЫШКА	64201768		●	●	●	●	●	●	●													
0815	ПЕЧАТНАЯ ПЛАТА LMS14 P23 CH04	65000640		●																			
	ПЕЧАТНАЯ ПЛАТА LMS14 P25 CH04	65000641			●																		
	ПЕЧАТНАЯ ПЛАТА LMS14 P26 CH04	65000642				●																	
	ПЕЧАТНАЯ ПЛАТА LMS14 P27 CH04	65000643					●																
	ПЕЧАТНАЯ ПЛАТА LMS14 P28 CH04	65000669						●															
	ПЕЧАТНАЯ ПЛАТА LMS14 P29 CH04	65000671								●													
0816	ПАНЕЛЬ УПРАВЛЕНИЯ AVS37.394/267 RMX	64201728		●	●	●	●	●	●	●													
0817	КАБЕЛЬ (AVS37.394)	64201726		●	●	●	●	●	●	●													
0822	РУКОЯТКА	65000588		●	●	●	●	●	●	●													
0825	МАНОМЕТР 1/4 0-8 бар	64201761		●	●	●	●	●	●	●													
0829	КАБЕЛЬ ЭЛЕКТРОДА ИОНИЗАЦИИ	64201858		●	●	●	●	●	●	●													
0830	КАБЕЛЬ ЭЛЕКТРОДА РОЗЖИГА	64201857		●	●	●	●	●	●	●													
0831	КОМПЛЕКТ ПРОВОДКИ	64201724		●	●	●	●	●	●	●													
0832	КАБЕЛЬ ДАТ.ДАВЛ.ВОДЫ/ТЕРМ.ПЕРЕГРЕВА	64201863		●	●	●	●	●	●	●													
5000	АКСЕССУАРЫ																						
5003	МОДУЛЬ OSI345.06/101 BSB-LPB BUS	64201617		●	●	●	●	●	●	●													
5005	КОМПЛЕКТ КАБЕЛЕЙ R40/65-150	64201874		●	●	●	●	●	●	●													

LIST OF THE ABBREVIATIONS

HW	: Hot water.
CW	: Cold water.
C	: Ceramic resistance (normal heating).
Ca	: Ceramic resistance (accelerated heating)
TP	: Immersion heater.
1F	: With fittings.
2F	: Without fittings.
3F	: With fittings and another outlet connection.
AMI	: With mixing valve.
SMI	: Without mixing valve.
PUISS	: Power of th appliance.
PN	: Appliance with normal pression.
LP	: Appliance with low pression.
PV	: Appliance with variable power.
PF	: Appliance with fixed power.

IDENTIFICATION PLATE

SERIAL NUMBER



The indications mentioned on the prices, commercial or technical literature and the scheme are written for your guidance and are available at a given time. The CONSTRUCTOR retains the power to modify the presentation, the form, the size, the conception or the material of the products.